
## USER INSTRUCTIONS

## Lumbar Massage Chair

## Panel Description:



## > Operation

- 1. Plug the AC Adapter into a power supply and input the DC end to the outlet of controller.
- 2. Press ( Power , to switch on the massage unit.
- 3. Press *imer* to switch the massage function to run from 15 to 30 minutes, If not pressed, the default time is 15 minutes.
- 4. Press strength ( to en hance the vibration in tensity, press strength ( to reduce the vibration intensity.

Please note :"position" and "mode" do not function on this chair.